



### TEXTALIGN (NEW COMMAND V\_2015)

**TEXTALIGN**  (New Command from Version - 2015)



Aligns multiple text objects vertically, horizontally, or obliquely.

Allows multiple text objects to be align to a base object and provides a preview of the result.

The following prompts are displayed  
Select text objects to align [alignment Options]

Select two or more objects to align and press Enter.



#### Alignment

Sets the alignment orientation

Left (Default setting) / **C**enter / **R**ight / **TL** (top left) / **TC** (top center) / **TR** (top right) / **ML** (middle left) / **MC** (middle center) / **MR** (middle right) / **BL** (bottom left) / **BC** (bottom center) / **BR** (bottom right)

Select all text objects to align

Select the text object to which others should align.

Pick second point or [Options]

After specifying a base object to align to, specify a second point to set the position of the target objects.


#### Options

Distribute :- Spaces objects evenly between two selected points.

Set Spacing :- Specifies spacing between the extents of the text objects.

Current Vertical :- Honors the current vertical positioning of the text object to be align

Current Horizontal :- Honors the current horizontal positioning of the text object to be align



(Example of Left & Center Alignments)